Pressure washers

K 2 Basic



The "K2 Basic" high-pressure cleaner is ideal for occasional use and removal of normal dirt around the home (e.g. bicycles, garden tools, garden furniture).

- High-pressure gun Standard Quick Connect
- Dirt blaster
- Pressure hose 3 m
- Detergent application via Suction
- Integrated water filter
- A3/4" garden hose connector adaptor

Order number: 1.673-151.0



Pressure (bar/MPa)	max. 110/max. 11
Flow rate I/h	max. 360
Area performance (m²/h)	20
Max. inlet temperature (°C)	max. 40
Connection load (kW)	1.4
Weight without accessories (kg)	4.08
Dimensions (L × W × H) (mm)	175.9x279.8x443
Frequency (Hz)	50-60
Voltage (V)	220-240

Hooked on tidiness

Generous cable hook for the tidy storage of the cable directly on the device.

Full cleaning power

All Kärcher pressure washer equipment includes an integrated suction mechanism for detergents.

Sits comfortably in the hand

The ergonomic carrying handle and low weight make the device easy and convenient to transport.

Accessories

Accessory kits

Accessory Kit Bike Cleaning

Order number 2.643-551.0



Wood Cleaning accessory kit

Order number 2.643-553.0



Accessory Kit Car Cleaning

Order number 2.643-554.0



Brushes

WB 60, Soft Surface Wash Brush

Soft brush for cleaning large areas, e.g. cars, caravans, boats, conservatories or roller shutters). Working width of 248 mm ensures good coverage.

Order number 2.643-233.0



WB 100, Rotating Wash Brush

Rotating washing brush with joint for cleaning all smooth surfaces, e.g. paint, glass or plastic. 18° infinitely adjustable joint on handle for cleaning difficult to reach areas.



Order number 2.643-236.0

Wheel Washing Brush

Wheel wash brush for effective cleaning also in difficult to reach areas. Uniform 360° water distribution for a perfect cleaning result.

Order number 2.643-234.0



Soft universal brush

Universal soft brush for cleaning all types of surfaces. With soft brushes, outer protector ring, union nut and rubber pad.



Order number 2.640-589.0

Brushes

Soft surface brush

Soft brush for cleaning large areas, e.g. cars, caravans, boats, conservatories or roller shutters). Working width of 248 mm ensures good coverage.

Order number 2.640-590.0



Rotary wash brush with joint

Rotating washing brush with joint for cleaning all smooth surfaces, e.g. paint, glass or plastic. 18° infinitely adjustable joint on handle for cleaning difficult to reach areas.



Order number 2.640-907.0

Power Brush PB 150

Order number 2.641-812.0



Soft Wash Brush WB 50

Universal soft brush for cleaning all types of surfaces. With soft brushes, outer protector ring, union nut and rubber pad.



Order number 2.643-246.0

Washing brush rigid

Slim brush for cleaning stubborn dirt

Order number 6.903-276.0



WB 150, Power Brush

WB 150 power brush for splash-free cleaning of sensitive surfaces. The effective combination of high pressure and manual brush pressure saves energy, water and up to 30% time.

Order number 2.643-237.0



Connectors/Tap adaptors

Universal hose coupling

Ergonomically designed universal hose coupling for convenient handling.

Order number 2.645-191.0



Hard surface cleaners

PS 40, Power Scrubber Surface Cleaner

PS 40 power scrubber with three integrated high-pressure nozzles. Powerful cleaning action removes stubborn dirt from surfaces quickly and easily. Ideal for stairs and edges.

Order number 2.643-245.0



T-Racer T 300 surface cleaner

T 300 T-Racer for spray-free surface cleaning. With adjustable cleaning pressure and extra handle for cleaning vertical surfaces. For Kärcher HomeGarden K 2 – K 7 pressure washers.

Order number 2.640-212.0



Replacement nozzle for T-Racer

High-quality, grey replacement nozzles for easy replacement of T-Racer nozzles. Suitable for replacing nozzles for the K2-K5 device classes.

Order number 2.640-727.0



PS 40 Power Scrubber

PS 40 power scrubber with three integrated high-pressure nozzles. Powerful cleaning action removes stubborn dirt from surfaces quickly and easily. Ideal for stairs and edges.

Order number 2.640-865.0



T 350, T-Racer Surface Cleaner

With the T-Racer Surface Cleaner T 350, large surfaces can be cleaned without splashing. Continuous pressure adjustment for hard and sensitive surfaces. Handle for vertical cleaning.



Order number 2.643-252.0

Replacement Nozzles Accessories

High-quality replacement nozzles for all T-Racer surface cleaners (except T 350) for unit classes K 2 to K 7, gutter cleaner PC 20 for K 3 to K 7, as well as chassis cleaner for K 2 to K 5.

Order number 2.643-338.0



Replacement Nozzles Accessories T 350

The high-quality replacement nozzles guarantee easy replacement of nozzles and are suitable for the T-Racer T 300 / T 350 surface cleaners for the pressure washer unit classes K 2 to K 7.

Order number 2.643-335.0



Hard surface cleaners

T-Racer T 250 Surface Cleaner

T 250 T-Racer for spray-free surface cleaning. With extra handle for cleaning vertical surfaces. The accessories are suitable for Kärcher HomeGarden pressure washers, classes K 2 - K 7.

Order number 2.642-194.0



High-pressure hose extension system up to 2007 and for devices without Quick Connect system

XH 10, Extension Hose

High-pressure extension hose for greater flexibility, 10 m robust DN 8 quality hose. Textile braiding reinforced, non-kinking hose with brass connector for durability.

Order number 6.389-092.0



High-Pressure Replacement Hose Kit system from 1992

HK 12, High-Pressure Hose Kit

Accessory kit for retrofitting the Quick Connect system. For all Consumer high-pressure cleaners manufactured since 1992.

Order number 2.642-953.0



HK 7.5, High-Pressure Hose Kit

Accessory set for retrofitting the practical Quick Connect system. For all Kärcher Consumer pressure washers manufactured since 1992. Not suitable for hose reel machines.

Order number 2.641-828.0



Adaptor Set Extension Hose

Two-part adaptor set for the connection of an extension hose with screw thread to a pressure washer with Quick Connect system.

Order number 2.643-037.0



High-pressure replacement hose: system from 2009 with Quick Connect system

H 9 Q, High-Pressure Hose Quick Connect

9 m high-pressure replacement hose for K 2 to K 7 pressure washers manufactured since 2009, on which the hose is attached to the spray gun and device with a Quick Connect quick coupling. 160 bar, 60°C.

Order number 2.641-721.0



High-pressure replacement hose: With anti-twist system and Quick Connect system.

H 10 Q PremiumFlex Anti-Twist

Innovative PremiumFlex pressure hose with anti-twist system to prevent tripping. 10 m long. Includes Quick Connect adaptor.



Order number 2.643-585.0

Hoses hose reels/trolleys

Hose set for pressure washers

Hose set for high pressure cleaning or for watering the garden. With 10 m PrimoFlex®-hose (3/4"), G3/4-tap adapter, 1 x Universal hose connector as well as Universal hose connector with Aqua Stop.

Order number 2.645-156.0



Hose set for water supply

Order number 2.645-258.0



PrimoFlex® hose 1/2" 20 m

The flexible PrimoFlex® (1/2") garden hose is a 20-metre-long, temperature-resistant and safe-to-operate water hose with pressure-resistant reinforcement. Bursting pressure: 24 bar.

Order number 2.645-138.0



Hose trolley HT 3.420 Kit 5/8

Compact hose trolley with height adjustable handle, angled hose connector, freewheeling crank, and innovative folding function for space-saving stowage. Fully assembled.

Order number 2.645-167.0



Premium Hose Reel HR 7.315 Kit 1/2"

Watering Station for the practical and space-saving stowage of hoses and garden accessories. With removable drum, storage possibility for nozzles, spray guns, and spray lances and spacious storage box. Fully equipped.

Order number 2.645-164.0



Miscellaneous

Water Filter

Water filter protects pressure washer pumps against dirt particles from dirty water.

Order number 4.730-059.0



Miscellaneous

O-Ring Set

Order number 2.640-729.0



G 160, Trigger Gun

Replacement gun for Kärcher K2 – K7 series domestic pressure washers. For all pressure washers where the hose is secured to the gun with a clip (without Quick Connect).

Order number 2.641-959.0



Garden Hose Adapter

Order number 2.640-732.0



Special applications

PC 7.5, Pipe Cleaning Kit, 7.5 m

Pipe cleaning set with 7.5 m hose for clearing blockages in pipes, drains, downpipes and toilets.

Order number 2.637-729.0



PC 15, Pipe Cleaning Kit, 15 m

Pipe cleaning set with 15 m hose for clearing blockages in pipes, drains, downpipes and toilets.

Order number 2.637-767.0



Sand and Wet-Blasting Kit

Sand and wet blasting set for removing rust, paint and stubborn dirt using Kärcher abrasive.

Order number 2.638-792.0



Vario Joint

Vario joint, rotates 180° for cleaning difficult to reach areas. Connection: For connection between gun and accessory or extension lance and accessory.

Order number 2.640-733.0



Special applications

Organiser

Kärcher organiser, the practical wall-mounted storage system for Kärcher accessories. With two modules for flexible mounting. Ideal for protecting wash brushes and bristles from bending.

Order number 2.641-630.0



FJ 6, Foam Jet

FJ 6 foam nozzle for cleaning with powerful foam (e.g. Ultra Foam Cleaner). For cars, motorcycles etc. and for applying cleaning products to stone and wood surfaces and façades.

Order number 2.643-147.0



FJ 10 C, Foam Jet Connect 'n' Clean, Ultra Foam Cleaner

Ultra Foam Cleaner + quick-change system FJ 10 C Connect 'n' Clean foam nozzle. Easy Change between different detergents with just a simple click.

Order number 2.643-143.0



FJ 10 C, Foam Jet Connect 'n' Clean, Car Shampoo 3-in-1

Car shampoo and + quick-change system FJ 10 C Connect 'n' Clean foam nozzle. Easy Change between different detergents with just a simple click.

Order number 2.643-144.0



FJ 10 C, Foam Jet Connect 'n' Clean, Stone Cleaner 3-in-1

Stone cleaner + quick-change system FJ 10 C Connect 'n' Clean foam nozzle. Easy Change between different detergents with just a simple click.

Order number 2.643-145.0



PC 20, Roof Gutter and Pipe Cleaning Kit, 20 m

The gutter and pipe cleaning kit works all by itself – with high pressure. It easily cleans outflows, pipe blockages and gutters.

Order number 2.642-240.0



Foam nozzle, 0.3 litre

Foam nozzle with powerful foam effortlessly cleans all types of surfaces, e.g. car or motorcycle paint, glass or stone, 0.3 litre container.

Order number 2.641-848.0



Special applications

Underbody cleaner

Highly effective chassis cleaner for removing dirt, mud, sludge, sand and encrusted salt. With care nozzle for applying chassis wax (incl. 250 ml free tester).

Order number 2.642-561.0



Spray lances

Angled Spray Lance

Extra-long angled spray lance (about 1 m) for easy cleaning of difficult to reach areas, e.g. roof gutters or vehicle underbodies.

Order number 2.638-817.0



1-step Lance Extension

Extends spray lance by 0.5 m. For effective cleaning of difficult to reach areas. Suitable for all Kärcher accessories.

Order number 2.643-240.0



3-step lance extension

3-stage lance extension set with four aluminium lances for difficult to reach areas. Variable extension to 90 cm, 1.30 m and 1.70 m.

Order number 2.639-722.0



Splash Guard

Splash guard for dirt blasterProtects against splash back when cleaning corners and edges. Fits all Kärcher dirt blasters (except 4.763-184).

Order number 2.640-916.0



VP 120, Vario Power Jet for K 2

Vario-Power spray lance: spray lance with infinitely variable pressure control from low-pressure detergent jet to high-pressure jet.

Order number 2.643-241.0



DB 145, Dirt Blaster for K 2 - K 4

Dirt blaster with powerful rotor nozzle (rotating pencil jet) ideal for removing stubborn dirt. Ideal for moss covered or weathered surfaces.

Order number 2.643-244.0

Spray lances

Telescopic Spray Lance

Telescopic spray lance (1.20 m - 4m) for easy cleaning of difficult to reach areas. With shoulder strap, bayonet connection and integrated, ergonomically adjustable trigger gun. Weight: ca. 2 kg

Order number 2.642-347.0



Vario Power Jet Short 360° VP 145 S for K 2 – K 4 Order number 2.643-253.0

